

## Creastar® Eye Liner

Distinctive and glamorous eye liner based on Creastar® Electrum, pearlescent pigments. Creastar® Electrum products are based on real silver and give intensive dark shine and colour in metallic shades of red, green, blue and violet. Creasil® 7 ID adds long lasting properties to the formulation.

Ingredients	INCI Name	Qty%	Supplier
<b>Phase A</b>			
	Water	q.s.	
	PVM/MA Decadiene Crosspolymer	0,50	
	Propylene Glycol	3,00	
	Tris-Amino	0,50	
<b>Phase B</b>			
	Lecithin	1,00	
<b>Creasil® 7 ID</b>	Isododecane (and) Dimethicone (and) Polyethacrylate	10,00	1)
<b>Phase C</b>			
<b>Creastar® Electrum TGR 60</b>	Calcium Alumina Borosilicate (and) CI 77820 (and) CI77891 (and) Silica (and) Tin Oxide	11,90	1)
<b>CreaBlack®</b>	(Black Iron Oxide) CI 77499	5,10	1)
<b>Phase D</b>			
	Alcohol	15,00	

### Procedure:

1. Heat up phase A to temperature of 75° C - 80° C and stir at the speed of 600-800rpm until homogenous.
2. Add phase B into phase A, keep heated and under agitation (800-1000rpm) for 15 minutes.
3. Homogenize (6000rpm) the mixture (A+B) and cool down to temperature below 35° C.
4. Adjust pH value to 7,60.
5. Add phases C and D, keep under strong agitation (1000-1200rpm) until homogenous.

**NOTE: Please note that sufficient preservative system needs to be used, we do not guarantee microbiological stability.**

### Suppliers:

- 1) CIT SARL/COSMO CHEM SARL

Note: Information contained in this technical literature is believed to be accurate and is offered in good faith for the benefit of the consumer. The company, however, cannot assume any liability or risk involved in the use of its formulations or chemical products, since the conditions of the use are beyond our control. Statements concerning the possible use of our products are not intended as recommendations to use products in the infringement of any patent. The information is for industrial and research use only. These formulations are not tested. We make no warranty of any kind, expressed or implied.

