

Make Up Remover

Soft and non-irritating make up remover for eyes, lips and facial area. Crealba® Sol is watersoluble texture enhancer, which brings out the benefits of Meadowfoam Seed Oil in new bio-functionalities. Crealba® Sol adds texture and slip to the formulation. Creasoluble® No.1 works as surfactant and solubiliser for water based solutions with a low level of alcohol. As a non-irritant and non-sensitising material, it can be used even in delicate applications.

Ingredients	INCI Name	Qty%	Supplier
Phase A	Water	q.s.	
	Butylene Glycol	5,00	
	Disodium EDTA	0,05	
	Chlorphenesin	0,20	
	Hexamidine Diisethionate	0,05	
Phase B	Poloxamer 407	1,00	
Phase C	Decyl Glucoside	5,00	
Crealba® Sol	Dimethicone PEG-8 Meadowfoamate	6,50	1)
Phase D			
Creasoluble® No.1	PPG-26-Buteth-26 (and) PEG-40 Hydrogenated Castor Oil (and) Water	0,60	1)
	Parfum	0,20	
Phase E	Chlorhexidine Digluconate	0,50	
Phase F			
FD&C Blue No.1 (0,15% in H₂O)	CI 42090 (and) Water	0,03	1)

Procedure:

1. Heat up phase A to temperature of 60° C and stir at the speed of 800-1000rpm until homogenous.
2. Cool down phase A to temperature below 35° C.
3. Add phases B, C, D, E and F into phase A under strong agitation (1000-1200rpm) until homogenous.
4. Adjust pH value to 6,40 – 6,50.

NOTE: Please note that sufficient preservative system needs to be used, we do not guarantee microbiological stability.

Suppliers:

- 1) CIT SARL/COSMO CHEM SARL

Note: Information contained in this technical literature is believed to be accurate and is offered in good faith for the benefit of the consumer. The company, however, cannot assume any liability or risk involved in the use of its formulations or chemical products, since the conditions of the use are beyond our control. Statements concerning the possible use of our products are not intended as recommendations to use products in the infringement of any patent. The information is for industrial and research use only. These formulations are not tested. We make no warranty of any kind, expressed or implied.

