

Wrinkle Correction

Wrinkle correction cream reduces fine lines and gives a smooth appearance to the skin. Biometrics® Emulsifier has excellent skin compatibility and it does not disrupt skin's natural barrier as traditional emulsifiers do. Dedraflow® 5 is emollient which replaces the use of cyclomethicone. Meadowfoam Seed Oil is a non-oxydizing vegetable oil with skin care benefits. Creanatural® BioCollagen is film former with moisture retaining properties. Siltext® products improve the application qualities and give a mat finish. Fiflow® is gas carrier which creates instant anti-wrinkle effect. As long term benefits, Fiflow® activates skin's own metabolism

Ingredients	INCI Name	Qty%	Supplier
Phase A	Water	q.s.	
	Glycerin	2,00	
	Butylene Glycol	2,50	
	Disodium EDTA	0,05	
	Hexamidine Diisethionate	0,05	
	Chlorphenesin	0,20	
	Xanthan Gum	0,20	
	Sodium Carboxymethylm Beta-Glucan	0,20	
	Polyvinyl Alcohol	0,50	
Biometrics® Emulsifier LHS	Sucrose Stearate (and) Hydrogenated Lecithin (and) Helianthus Annuus (Sunflower) Wax (and) Helianthus Annuus (Sunflower) Seed Oil (and) Xanthan Gum (and) Tocopherol (and) Chlorphenesin	4,00	1)
Phase B	Behenyl Alcohol	1,60	
	Glyceryl Monostearate	1,50	
Creabase® NTL 80	Hydrogenated Polydecene (and) Polyethylene (and) Isohexadecane	1,00	1)
Dedraflow® 5	Hydrogenated Polyisobutene	5,00	1)
Meadowfoam Seed Oil®	Limnanthes Alba (Meadowfoam) Seed Oil	2,00	1)
	Glyceryl Linoleate (and) Glyceryl Oleate (and) Glyceryl Linolenate	2,00	
	Tocopherol Acetate	1,00	
	Caprylyl Glycol		
Phase C			
Creanatural® BioCollagen	Water (and) Glycerine (and) Butylene Glycol (and) Zea Mays (Corn) Starch (and) Natto Gum (and) Citric Acid (and) Chlorphenesin	5,00	1)
	Hyaluronic Acid	0,05	
Phase D			
	Parfum	0,35	
Siltext® Mat	Hydrogenated Polyisobutene (and) Dimethicone Crosspolymer	3,00	1)
Siltext® Velvet	Hydrogenated Polyisobutene (and) Dimethicone (and) Polyethylacrylate	2,00	1)
Phase E			
Fiflow® 135	Perfluorodecalin (and) Perfluorononane (and) Perfluorohexane (and) Perfluoroperhydrophenanthrene (and) Perfluorodimethylcyclohexane	5,00	1)

Procedure:

- Heat up water and Biometrics® Emulsifier to temperature of 70° C - 75° C until a milk is developed. Add the rest of the ingredients in phase A and stir at the speed of 500-600rpm until homogenous.
- Heat up phase B to temperature of 70° C - 75° C and stir at the speed of 500-600rpm until homogenous.
- Add phase B into phase A and keep agitated (1000-1200rpm) and heated for 15 minutes.
- Homogenize (6000rpm) the mixture (A+B) and cool down the mixture (A+B) to temperature below 35° C.
- Mix phase C and leave to swell for 20 minutes. Add phase C into the mixture (A+B). Homogenize the mixture (A+B+C).
- Add phase D into the mixture. Homogenize(6000rpm) the mixture (A+B+C+D) for 1-2 minutes.
- Add phase E into the mixture. Homogenize (6000rpm) the mixture (A+B+C+D+E) for 1-2 minutes.

Suppliers:

- 1) CIT SARL/COSMO CHEM SARL

Note: Information contained in this technical literature is believed to be accurate and is offered in good faith for the benefit of the consumer. The company, however, cannot assume any liability or risk involved in the use of its formulations or chemical products, since the conditions of the use are beyond our control. Statements concerning the possible use of our products are not intended as recommendations to use products in the infringement of any patent. The information is for industrial and research use only. These formulations are not tested. We make no warranty of any kind, expressed or implied.

