

Facial Mask

Facial mask is based on Fiflow® as an active ingredient. Fiflow® is a gas carrier which gives instant anti-wrinkle effects with feeling of coolness. Creanatural® Vegetable Squalene mimic's skin's own sebum and therefore has excellent skin moisture retention properties. Crealba® Sol brings the benefits of non-oxydazing Meadowfoam Seed Oil in addition to silky skin feel. Micapoly® works as filler and texturizing agent. Nylonpoly® improves the sensorial perceptions of the product as well as reduces any tackiness in the formulation.

Ingredients	INCI Name	Qty%	Supplier
Phase A			
	Water	q.s.	
	Sclerotium Gum	0,80	
	Glyceryl Laurate	10,00	
	TEA-Lauryl Sulfate	15,00	
	Decyl Glucoside	12,00	
	Disodium Laureth Sulfosuccinate	4,00	
Phase B			
Crealba® Sol	Dimethicone PEG-8 Meadowfoamate	2,00	1)
Creanatural® Vegetable Squalene	Squalene	2,00	1)
	Parfum	0,50	
	Methylisothiazolinone (and) Chlorphenesin	1,00	
Phase C			
Micapoly® WL 20 PUR	Mica	1,50	1)
Nylonpoly® WL 20 PUR	Nylon-12	1,50	1)
Phase D			
Fiflow® 135	Perfluorodecalin (and) Perfluorononane (and) Perfluorohexane (and) Perfluoroperhydrophenanthrene (and) Perfluorodimethylcyclohexane	10,00	1)

Procedure:

1. Mix and heat water and Sclerotium Gum to temperature of 70-75°C and leave to swell for 20 minutes.
2. Cool down to temperature below 35°C and add the rest of the ingredients in phase A.
3. Add phase B into phase A and keep under agitation (1000-1200rpm) for 15 minutes.
4. Homogenize(6000rpm) the mixture (A+B) for 5 minutes.
5. Add phase C into the mixture (A+B) and homogenize(6000rpm) for 2-3 minutes.
6. Add phase D into the mixture (A+B+C) and homogenize (6000rpm) for 1-2 minutes.

NOTE: Please note that sufficient preservative system needs to be used, we do not guarantee microbiological stability.

Suppliers:

- 1) CIT SARL/COSMO CHEM SARL

Note: Information contained in this technical literature is believed to be accurate and is offered in good faith for the benefit of the consumer. The company, however, cannot assume any liability or risk involved in the use of its formulations or chemical products, since the conditions of the use are beyond our control. Statements concerning the possible use of our products are not intended as recommendations to use products in the infringement of any patent. The information is for industrial and research use only. These formulations are not tested. We make no warranty of any kind, expressed or implied.

