

"1000 Minutes of Colour®" Foundation (Yellow)

Transformation type formulation, which appears white when dispensed, but develops colour when applied onto the skin. Coloursphere® composite colourants work together with Creasperse® UV-dispersion to create this transformation upon application and the Creasperse® UV-dispersion offers SPF and high UVA-protection at the same time. Creasil® IH CG and Alphaflow® 30 are suitable lightweight emollients for a foundation as they are photostable materials. Creaspheres® PMMA WL 6 and Siltext® Velvet are added to improve application qualities and to bring mattness and smoothness to the finished application.

Ingredients	INCI Name	Qty%	Supplier
Phase A			
	Cetyl PEG/PPG-10/1 Dimethicone	2,00	
	Lauryl PEG/PPG-18/18 Methicone	1,00	
Dedraflow® 5	Hydrogenated Polyisobutene	5,50	1)
Hectone® DF	Hydrogenated Polyisobutene (and) Distearidimonium Hectorite (and) Propylene Carbonate	1,20	1)
	Dimethicone	2,50	
Creasil® IH CG	Isohexadecane	10,00	1)
Alphaflow® 30	Hydrogenated Polydecene	4,00	1)
Meadowfoam Seed Oil®	Limnanthes Alba (Meadowfoam) Seed Oil	3,00	1)
	Cetyl Dimethicone	2,00	
Phase B			
	Water	q.s.	
	Glycerin	6,00	
	Butylene Glycol	3,00	
	PEG-400	3,00	
	Sodium Chloride	1,00	
	Disodium EDTA	0,05	
	Chlorphenesin	0,20	
Phase C			
Coloursphere® Yellow HL	CI 77492 (Iron Oxides) (and) Styrene/Acrylates Copolymer (and) PEG 26-PPG 30 Phosphate	1,50	1)
Coloursphere® White R HL	CI 77891 (Titanium dioxide) (and) Styrene/Acrylates Copolymer (and) PEG 26-PPG 30 Phosphate	0,42	1)
Creaspheres® PMMA WL 6	Methyl Methacrylate Crosspolymer	3,00	1)
Phase D			
Siltext® Velvet	Hydrogenated Polyisobutene (and) Dimethicone (and) Polyethylacrylate	5,00	1)
Creasperse® TR 35 AF 65	Titanium Dioxide (and) Hydrogenated Polydecene (and) Hydroxystearic Aci	15,00	1)
BNPoly® UV Crystal TR22	Boron Nitride (and) Titanium Dioxide (and) Dimethicone (and) Isododecane (and) Ethylene/VA Copolymer	2,00	1)
	Parfum	0,40	

SPF in vitro: 33,4

UVA Ratio: 0,75

Star Category: ***

Critical Wavelength: 381nm

Procedure:

1. Heat up the phase A to temperature of 75°C.
2. Heat up the phase B to temperature of 75°C.
3. When both phases are at 75°C, pour phase B into phase A, keep heating under agitation 800-900 rpm for 15-20 minutes.
4. Homogenize mixture (A+B) for 5 minutes.
5. Cool down the mixture down to temperature below 40°C, and add phase D. Homogenize for 2-3 minutes.
6. In the end, add phase C and stir at the speed of 500-600 rpm until mixture is homogeneous.
7. Adjust the pH value to 5,80 – 6,50.

NOTE: Please note that sufficient preservative system needs to be used, we do not guarantee microbiological stability.

Suppliers: 1) CIT SARL/COSMO CHEM SARL

Note: Information contained in this technical literature is believed to be accurate and is offered in good faith for the benefit of the consumer. The company, however, cannot assume any liability or risk involved in the use of its formulations or chemical products, since the conditions of the use are beyond our control. Statements concerning the possible use of our products are not intended as recommendations to use products in the infringement of any patent. The information is for industrial and research use only. These formulations are not tested. We make no warranty of any kind, expressed or implied.

